




















Griff - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 20 89 010 10



	Messing gebürstet (23kt Gold)	90 20 89 010 10-28
	Chrom	90 20 89 010 10-00
	Platin gebürstet	90 20 89 010 10-06
	Platin	90 20 89 010 10-08
	Messing (23kt Gold)	90 20 89 010 10-09
	Weiß matt	90 20 89 010 10-10
	schwarz	90 20 89 010 10-13
	Dark Chrome	90 20 89 010 10-19
	Light Gold	90 20 89 010 10-26
	Light Gold gebürstet	90 20 89 010 10-27
	Rot	90 20 89 010 10-29
	Schwarz matt	90 20 89 010 10-33
	Dark Brass gebürstet	90 20 89 010 10-39
	Bronze gebürstet	90 20 89 010 10-42
	Champagne gebürstet (22kt Gold)	90 20 89 010 10-46
	Champagne (22kt Gold)	90 20 89 010 10-47
	Cyprum	90 20 89 010 10-49
	Chrom gebürstet	90 20 89 010 10-93
	Dark Platinum gebürstet	90 20 89 010 10-99



Griff - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 20 89 010 10



Griff - Messing gebürstet (23kt Gold)

ERSATZTEILE

90 20 89 010 10

90 20 89 010 10

Ersatzteile für die
anderen
Oberflächenvarianten
finden Sie hier:
Chrom

