



Technische Daten

Warmwasserspeicher

HT 200 - 300 - 400 - 500 ERM




Die Standfüße dürfen NICHT für Transportzwecke verwendet werden!

Type	Abmessungen in mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Technical data

Hot water tank
HT 200 - 300 - 400 - 500 ERMR




The support pedestals must NOT be used for transport purposes!

Type	Dimensiones in mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Caractéristiques techniques

Ballon d'eau chaude
HT 200 - 300 - 400 - 500 ERMR




Les piétements NE doivent PAS servir au transport !

Type	Dimesions en mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Dati tecnici

Bollitore acqua calda
HT 200 - 300 - 400 - 500 ERMR




NON usare i piedini per il trasporto!

Type	Dimensioni in mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Datos técnicos

Acumulador de agua caliente
HT 200 - 300 - 400 - 500 ERMR




¡Está PROHIBIDO utilizar las patas de apoyo para el transporte!

Type	Dimensiones en mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Tehnični podatki

Zbiralnik za toplo vodo

HT 200 - 300 - 400 - 500 ERMR




Podnožja NE smete uporabljati v transportne namene!

Type	Dimenzije v mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Tehnički podaci

Bojler za toplu vodu

HT 200 - 300 - 400 - 500 ERMR




Nožice NE SMIJETE koristiti za potrebe prijevoza!

Type	veličina in mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

Technická data

Zásobník teplé vody

HT 200 - 300 - 400 - 500 ERMR




Opěrné nohy se NESMĚJÍ použít pro přepravu!

Type	Rozměry v mm													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

технические характеристики

аккумулирующая емкость для горячей воды

HT 200 - 300 - 400 - 500 ERMR



ЗАПРЕЩЕНО использовать опорные ножки для транспортировки!

модель	размеры в мм													
	H	D	A	B	C	E	F	G	I	J	K	L	M	N
HT 200 ERMR	1340	610	263	638	870	750	1020	305	695	1050	360	688	878	310
HT 300 ERMR	1797	610	263	818	983	1083	1488	305	983	1507	360	868	1257	370
HT 400 ERMR	1832	680	305	910	1000	1145	1460	345	1000	1521	420	960	1317	370
HT 500 ERMR	1838	760	370	930	1040	1150	1465	370	1095	1498	475	980	1323	310

de Produktdatenblatt ErP
 en Product fiche ErP
 fr Fiche de produit ErP
 it Scheda prodotto ErP
 es Hoja de datos del producto ErP
 sl Podatki o izdelku ErP
 hr Listovi s podacima o proizvodu ErP
 cz List výrobku ErP
 ru Технический паспорт продукта



Modell - model - modèle - modello - modelo - Type - модель	HT ERMR			
	200	300	400	500
Energieeffizienzklasse Energy efficiency class Classe d'efficacité énergétique Classe di efficienza energetica Clase de eficiencia energética energijski razred Razred energetske učinkovitosti Energetická třída Класс энергоэффективности	C	C	C	C
Warmhalteverlust W Standing loss Pertes statiques Dispersione Pérdida de Calentamiento toplotnih izgub gubitak zagrijavanje ztráta oteplování потеря потеря	70	91	102	113
Speichervolumen L Tank volume Capacité de stockage Volume utile Volumen de la caldera nazivna moč kapaciteta kapacita номинальная мощность	200	300	400	500