


















## Griff Hebel 50 x 46 x 124 mm - Chrom

## ERSATZTEILE

09 20 67 014



	Chrom	09 20 67 014-00
	Platin gebürstet	09 20 67 014-06
	Platin	09 20 67 014-08
	Dark Brass matt	09 20 67 014-16
	Dark Bronze matt	09 20 67 014-17
	Dark Chrome	09 20 67 014-19
	Light Gold gebürstet	09 20 67 014-27
	Messing gebürstet (23kt Gold)	09 20 67 014-28
	Schwarz matt	09 20 67 014-33
	Dark Brass gebürstet	09 20 67 014-39
	Bronze gebürstet	09 20 67 014-42
	Champagne gebürstet (22kt Gold)	09 20 67 014-46
	Champagne (22kt Gold)	09 20 67 014-47
	Cyprum	09 20 67 014-49
	Chrom gebürstet	09 20 67 014-93
	Dark Platinum gebürstet	09 20 67 014-99



## Griff Hebel 50 x 46 x 124 mm - Chrom

ERSATZTEILE

09 20 67 014



## Griff Hebel 50 x 46 x 124 mm - Chrom

ERSATZTEILE

09 20 67 014