















Auslauf für Waschtisch Stand 180,5 x 64 x 191,7 mm - Chrom

ERSATZTEILE

04 11 36 001 10



	Chrom	04 11 36 001 10-00
	Gold (23,9kt)	04 11 36 001 10-01
	bronze	04 11 36 001 10-02
	altmessing	04 11 36 001 10-03
	Platin gebürstet	04 11 36 001 10-06
	Platin	04 11 36 001 10-08
	Messing (23kt Gold)	04 11 36 001 10-09
	weiß	04 11 36 001 10-12
	Dark Brass matt	04 11 36 001 10-16
	Dark Bronze matt	04 11 36 001 10-17
	Messing gebürstet (23kt Gold)	04 11 36 001 10-28
	Dark Brass gebürstet	04 11 36 001 10-39
	Bronze gebürstet	04 11 36 001 10-42
	Dark Platinum gebürstet	04 11 36 001 10-99



Auslauf für Waschtisch Stand 180,5 x 64 x 191,7 mm - Chrom

ERSATZTEILE

04 11 36 001 10



Auslauf für Waschtisch Stand 180,5 x 64 x 191,7 mm - Chrom

ERSATZTEILE

04 11 36 001 10